

Installation Instructions

- 1. Screw adapter into pump outlet***
- 2. Place clamp over cuff of tubing***
- 3. Push tubing onto adapter and tighten clamp***