


Deluxe Adirondack Chair

Customer Service:
Decko Products
2301 Traffic St. NE
Minneapolis, MN 55413
1-800-495-9278

Model # 82150, 82100, 82152, 82158

Thank You for your purchase of a finely crafted Adirondack Chair from Decko Products. The following contains assembly instructions as well as care and maintenance suggestions. Please take a moment to completely read and familiarize yourself with this information. You will then be ready to assemble your chair. If you have any questions regarding your purchase, please contact us at 1-800-495-9278



Your Decko Adirondack chair is made from high quality, select grade fir. It is naturally resistant to rot and decay. The wood is pre-finished with a high quality oil base stain or paint which will protect it from the elements. It is recommended to re-apply a high quality oil stain or paint each year or when the finish shows signs of wear. This will ensure years of trouble free use.


TOOLS REQUIRED FOR ASSEMBLY: Phillips screwdriver, adjustable wrench

MAINTENANCE: Very little maintenance is required for your furniture. Periodically check all fasteners to make sure they are properly secured. Re-tighten if necessary.

NOTE: It is **NOT** recommended to use power tools for assembly. They may cause over tightening and damage to your furniture.

Limited Warranty: This product is covered under the manufacturer's 1 year limited warranty against defects in workmanship and materials. If your Backyard Creations® furniture fails structurally during normal use within one year of purchase, the manufacturer will repair or replace the defective piece at no charge. The warranty excludes furniture used for commercial purposes, furniture damaged by acts of nature, abuse or lack of proper care or use of improper hardware. Proof of purchase (dated register receipt) is required for warranty claims.

Parts List




A Seat Assembly
QTY: 1




B Back Assembly
QTY: 1




C Back Support
QTY: 2




D Left Leg
QTY: 1



E Right Leg
QTY: 1



F 2-1/4" Bolts
QTY: 2




G 2" Bolts
QTY: 10




H Washers
QTY: 12



I Nuts
QTY: 12



M 2-1/2" Wood Screws
QTY: 2



J 1-1/2" Wood Screws
QTY: 8




K Left Arm
QTY: 1

L Right Arm
QTY: 1


Step 1 Assembly

Attach the back assembly (B) to the seat assembly (A) using four 1-1/2" wood screws (J). Securely tighten with a phillips screwdriver.




Step 2 Assembly

Attach the left (D) and right (E) legs to the seat assembly using six 2" bolts (G), washers (H), and nuts (I).



Step 3 Assembly




1. Attach the bottom of the back support (C) to the seat assembly using two 2" bolts (G), washers (H) and nuts (I). Finger tighten only at this time.

2. Attach the top of the back support (C) to the back assembly using two 1-1/2" wood screws (J). Securely tighten with a phillips screwdriver.

3. Repeat above steps for assembly on the left side and securely tighten all fasteners.

Step 4 Assembly



1. Attach the back of the left arm (K) to the chair assembly using a 2-1/2" wood screw (M).

2. Attach the front of the arm (K) to the leg using a 2-1/4" bolt (F), washer (H) and nut (I). Note the orientation of the bolt in the figure.

3. Repeat above steps for assembly on the right side and securely tighten all fasteners.

You are Finished!
Enjoy Your Chair

Customer Support
1-800-495-9278