


DECORATIVE INSERT MANUAL

DECORATIVE INSERTS FIT

32" MODEL # 27242 SKU: 419-1291

36" MODEL # 27246 SKU: 419-1292



32" MODEL # 27270 SKU: 419-1293

36" MODEL # 27271 SKU: 419-1294




32" MODEL # 27272 SKU: 419-1295

36" MODEL # 27273 SKU: 419-1296



32" MODEL # 27274 SKU: 419-1297

36" MODEL # 27275 SKU: 419-1298



Step 1:
Locate the frame channel inside the door frame. The frame channel is only located on one side of the door.

Frame channel location

Step 2:
Insert the bottom edge of one decorative insert into the frame channel.

Step 3:
Swing insert up and into the door frame. Push insert down into frame channel to secure insert.

NOTE:
Wood glue may be added to the frame channel for added strength.

Step 4:
Enjoy your new door.

Home Sweet Home

ALL INSERTS AND DOORS SOLD SEPARATELY